

HYDRA



Annihilate BA

Total Disinfectant



HYDRA®

Features & Advantages

- **Wide spectrum.** Effectively destroys all viruses and harmful bacteria.
- Cleans up heavy soiling, smoke residues, body fluid and blood contamination.
- Use for **preventing cross infection.**
- **Colour indicator** included to ensure disinfection with every use. **Use fresh solution when gold colour is lost**, indicating exhausted disinfecting properties.
- Use for cleaning and disinfecting suits, BA masks, boots, gloves, suits and other medical equipment.
- **Quick action, non-persistent, non-corrosive, non-toxic** formula that is safe to use on most surfaces for disinfection and cleaning purposes.
- Use safely upon synthetic material including polypropylene, paint work, neoprene, rubber, nylon
- Clean and disinfects all metallic surfaces including titanium and stainless steel.

Description



Hydra Annihilate BA

Safely and Rapidly Removes Smoke, Soiling, Blood & Body Fluids.

Fast acting, biodegradable, non-persistent, non-corrosive, non-toxic, dual purpose disinfectant/cleaner.

Removes smoke, soils, blood and body fluids.

Multi Purpose

Unlike disinfectants which only work on clean surfaces, Annihilate BA disinfects as it removes the contamination, ensuring total disinfecting first time.

Safe

For use on all rubber, polypropylene, neoprene, nylon and other synthetics.

All metals including stainless steel and titanium.



The Solution

Colour Indicator

Containing a colour indicator. In use the solution is gold. Once the disinfecting power has been exhausted the solution will lose colour. Renew with fresh solution.

Powerful Biocides Stops Infection and Cross Infection

Highly effective against the many harmful micro-organisms connected with respiratory fluids found in breathing apparatus. Also destroys bacteria and viruses found in suits, boots and gloves.



Highly Effective Against

Viruses— Including: Influenza A2 (Asian), Avian Flu A (HPAI) (H5N1) (H7) Foot & Mouth Disease (FMDV), Mycobacterium Tuberculosis, Hepatitis B, Poliomyelitis, HIV (Aids), Coxsackie B, ECHO 6, Adenovirus 2, Coronavirus (COVID-19), Herpes Simplex, Vaccinia, Weil's disease and Orf.
Fungi - Trichophyton Interdigitale, Epidermophyton Floccomum, Candida Albicans (Yeast).
Algae - Protozoa including air borne spores.
Bacteria - Straphylococcus Aereus, Streptococcus Pyogenes Pseudomonas Aeroginosa, Escherichia Coli.

How To Use

- **Cleans & Disinfects In One Step**
- **Removes Smoke & Body Fluids**
- **Stops Infection & Cross Infection**
- **Safe Biodegradable Disinfectant**

Method of Use:

Dilute 1:50 with water. (200ml to 10L water)
Renew solution once golden colour has faded.
Make fresh solution daily.

B.A. Masks - Disinfect, Remove Smoke damage and general soiling

Make up solution. Immerse parts to be cleaned.
Rub lightly.

To Disinfect soak item for 5 minutes, rinse and dry.

To Clean/Remove Smoke Damage soak for minimum 5 minutes or longer to remove gross soiling, rinse and dry.



Laboratory Facilities

Hydra International Ltd.'s Research & Development Laboratories are a hub of activity where new products are developed and formulated. We have working relationships with our raw material suppliers, many of these suppliers are major world-wide chemical manufacturers with their own development laboratories.

As a company we are well known in the chemical industry for being receptive to cutting edge new chemicals which can be incorporated into our products to achieve performance advantages. An important part of the International Standards that we hold is that of constant improvement. We show that we have achieved this at every independent audit.



Hydra International Ltd
Milton Keynes MK11 3ER, UK
01908-265889
sales@hydra-int.com
www.hydra-int.com

